

Now let's move on to MSHV.

Let's go to Options and then to Macro. We would have this screen:

MSHV

Macros | Network Configuration | Radio And Frequencies Configuration

Distance unit: Kilometers Miles

Macros By Region: Region 1 Region 2 Region 3

Macros option for JTMS,FSK,ISCAT,JT6M: Report Grid RSQ And Serial Number

Macros option for MSK,FT,Q65: Activity Type: Standard

ARRL Field Day Exch: 1D NB Roundup Exch: DX

Multi-Two Transmitter: (Requires Two Different Installed Copies Of Software) None

Macros:

My call =%M His call =%T RST or RSQ =%R 4 characters locator =%G4
6 characters locator =%G6 Random QRG =%QRG Serial number =%N
My suffix =%O His suffix =%H Separating numeral + my suffix =%SO
Separating numeral + his suffix =%SH

GEN MESSAGE

MY CALL: IK8OZV GRID LOCATOR: JN70KW

Macros for JTMS,FSK,ISCAT,JT6M

Tx1 %T %M
Tx2 %T %M %R %R
Tx3 %T %M R%R R%R
Tx4 RRRR RRRR %M
Tx5 73 %M
Tx6 CQ %M
Tx7 CQ %QRG %M

SET DEFAULT MACROS

Macros for MSK,FT,Q65,JT65

Tx1 %T %M %G4
Tx2 %T %M %R
Tx3 %T %M R%R
Tx4 %T %M RR73
Tx5 %T %M 73
Tx6 CQ %M %G4
Tx7 CQ %QRG %M %G4

SET DEFAULT MACROS

Let's click on the Network Configuration tab:

MSHV

Macros | **Network Configuration** | Radio And Frequencies Configuration

Distance unit: Kilometers Miles

Macros By Region: Region 1 Region 2 Region 3

Macros option for JTMS,FSK,ISCAT,JT6M: Report Grid RSQ And Serial Number

Macros option for MSK,FT,Q65: Activity Type: Standard

ARRL Field Day Exch: 1D NB Roundup Exch: DX

Multi-Two Transmitter: (Requires Two Different Installed Copies Of Software) None

Macros:
 My call =%M His call =%T RST or RSQ =%R 4 characters locator =%G4
 6 characters locator =%G6 Random QRG =%QRG Serial number =%N
 My suffix =%O His suffix =%H Separating numeral + my suffix =%SO
 Separating numeral + his suffix =%SH

GEN MESSAGE

MY CALL: IK8OZV GRID LOCATOR: JN70KW

Macros for JTMS,FSK,ISCAT,JT6M	Macros for MSK,FT,Q65,JT65
Tx1 %T %M	Tx1 %T %M %G4
Tx2 %T %M %R %R	Tx2 %T %M %R
Tx3 %T %M R%R R%R	Tx3 %T %M R%R
Tx4 RRRR RRRR %M	Tx4 %T %M RR73
Tx5 73 %M	Tx5 %T %M 73
Tx6 CQ %M	Tx6 CQ %M %G4
Tx7 CQ %QRG %M	Tx7 CQ %QRG %M %G4
SET DEFAULT MACROS	SET DEFAULT MACROS

And we would have this screen that interests us:

MSHV

Macros Network Configuration Radio And Frequencies Configuration

PSK Reporter Settings:

Enable PSK Reporter Spotting Use TCP/UDP Protocol

Status: **PSK Reporter Is Disabled And Disconnected**

Server: Port:

DX-Spot Settings:

Status: **Disconnected**

Server: Port:

Telnet Clusters:

UDP Broadcast Settings:

Enable Logged QSO Enable Logged QSO ADIF Enable Decoded Text

Status: **UDP Broadcast Is Disabled And Disconnected**

Server: Port:

Write Status Info In To File (settings/mshv_status.txt)

Simplified UDP Broadcast: Enable Logged QSO ADIF

Server: Port:

TCP Broadcast Settings: - DXKeeper Formatted Message -

Server: Port: Enable Logged QSO

Club Log Real-Time Upload Logged QSO:

Server: Port: Post:

E-Mail: Password: Callsign: **IK8OZV** Enable

QRZ Logbook Real-Time Upload Logged QSO:

Server: Port: Post:

API Key: Enable

eQSL Real-Time Upload Logged QSO:

Server: Port: Post:

User: Password: QTH Nickname:

eQSL MSG: Enable

At this point put the X in the "Enable Logged Qso" box of the section

"UDP Broadcast Settings:"

MSHV

Macros Network Configuration Radio And Frequencies Configuration

PSK Reporter Settings:

Enable PSK Reporter Spotting Use TCP/UDP Protocol

Status: **PSK Reporter Is Disabled And Disconnected**

Server: Port:

DX-Spot Settings:

Status: **Disconnected**

Server: Port:

Telnet Clusters:

UDP Broadcast Settings:

Enable Logged QSO Enable Logged QSO ADIF Enable Decoded Text

Status: **Connected to Enzo IP 127.0.0.1**

Server: Port:

Write Status Info In To File (settings/mshv_status.txt)

Simplified UDP Broadcast: Enable Logged QSO ADIF

Server: Port:

TCP Broadcast Settings: - DXKeeper Formatted Message -

Server: Port: Enable Logged QSO

Club Log Real-Time Upload Logged QSO:

Server: Port: Post:

E-Mail: Password: Callsign: **IK8OZV** Enable

QRZ Logbook Real-Time Upload Logged QSO:

Server: Port: Post:

API Key: Enable

eQSL Real-Time Upload Logged QSO:

Server: Port: Post:

User: Password: QTH Nickname:

eQSL MSG: Enable

Once you put the X you should see the State go from "Disconnection.....", to "Connected to..." in green:

MSHV

Macros Network Configuration Radio And Frequencies Configuration

PSK Reporter Settings:

Enable PSK Reporter Spotting Use TCP/UDP Protocol
Status: **PSK Reporter Is Disabled And Disconnected**
Server: Port:

DX-Spot Settings:

Status: **Disconnected**
Server: Port:
Telnet Clusters:

UDP Broadcast Settings:

Enable Logged QSO Enable Logged QSO ADIF Enable Decoded Text
Status: **Connected to Enzo IP 127.0.0.1**
Server: Port:
 Write Status Info In To File (settings/mshv_status.txt)

Simplified UDP Broadcast: Enable Logged QSO ADIF
Server: Port:

TCP Broadcast Settings: - DXKeeper Formatted Message -
Server: Port: Enable Logged QSO

Club Log Real-Time Upload Logged QSO:

Server: Port: Post:
E-Mail: Password: Callsign: **IK8OZV** Enable

QRZ Logbook Real-Time Upload Logged QSO:

Server: Port: Post:
API Key: Enable

eQSL Real-Time Upload Logged QSO:

Server: Port: Post:
User: Password: QTH Nickname:
eQSL MSG: Enable

At this point leave the Server field set to 127.0.0.1

MSHV

Macros | Network Configuration | Radio And Frequencies Configuration

PSK Reporter Settings:

Enable PSK Reporter Spotting Use TCP/UDP Protocol

Status: **PSK Reporter Is Disabled And Disconnected**

Server: Port:

DX-Spot Settings:

Status: **Disconnected**

Server: Port:

Telnet Clusters:

UDP Broadcast Settings:

Enable Logged QSO Enable Logged QSO ADIF Enable Decoded Text

Status: **Connected to Enzo IP 127.0.0.1**

Server: Port:

Write Status Info In To File (settings/mshv_status.txt)

Simplified UDP Broadcast: Enable Logged QSO ADIF

Server: Port:

TCP Broadcast Settings: - DXKeeper Formatted Message -

Server: Port: Enable Logged QSO

Club Log Real-Time Upload Logged QSO:

Server: Port: Post:

E-Mail: Password: Callsign: Enable

QRZ Logbook Real-Time Upload Logged QSO:

Server: Port: Post:

API Key: Enable

eQSL Real-Time Upload Logged QSO:

Server: Port: Post:

User: Password: QTH Nickname:

eQSL MSG: Enable

And set the Door, if it's not already set like this on 2337:

MSHV

Macros | Network Configuration | Radio And Frequencies Configuration

PSK Reporter Settings:

Enable PSK Reporter Spotting Use TCP/UDP Protocol

Status: **PSK Reporter Is Disabled And Disconnected**

Server: Port:

DX-Spot Settings:

Status: **Disconnected**

Server: Port:

Telnet Clusters:

UDP Broadcast Settings:

Enable Logged QSO Enable Logged QSO ADIF Enable Decoded Text

Status: **Connected to Enzo IP 127.0.0.1**

Server: Port:

Write Status Info In To File (settings/mshv_status.txt)

Simplified UDP Broadcast: Enable Logged QSO ADIF

Server: Port:

TCP Broadcast Settings: - DXKeeper Formatted Message -

Server: Port: Enable Logged QSO

Club Log Real-Time Upload Logged QSO:

Server: Port: Post:

E-Mail: Password: Callsign: Enable

QRZ Logbook Real-Time Upload Logged QSO:

Server: Port: Post:

API Key: Enable

eQSL Real-Time Upload Logged QSO:

Server: Port: Post:

User: Password: QTH Nickname:

eQSL MSG: Enable

Let's go down slightly always in the same section, and enable where it says "Enable Logged QSO

ADIF" putting the X to the left of the wording:

MSHV

Macros Network Configuration Radio And Frequencies Configuration

PSK Reporter Settings:

Enable PSK Reporter Spotting Use TCP/UDP Protocol

Status: **PSK Reporter Is Disabled And Disconnected**

Server: Port:

DX-Spot Settings:

Status: **Disconnected**

Server: Port:

Telnet Clusters:

UDP Broadcast Settings:

Enable Logged QSO Enable Logged QSO ADIF Enable Decoded Text

Status: **Connected to Enzo IP 127.0.0.1**

Server: Port:

Write Status Info In To File (settings/mshv_status.txt)

Simplified UDP Broadcast: Enable Logged QSO ADIF

Server: Port:

TCP Broadcast Settings: - DXKeeper Formatted Message -

Server: Port: Enable Logged QSO

Club Log Real-Time Upload Logged QSO:

Server: Port: Post:

E-Mail: Password: Callsign: **IK8OZV** Enable

QRZ Logbook Real-Time Upload Logged QSO:

Server: Port: Post:

API Key: Enable

eQSL Real-Time Upload Logged QSO:

Server: Port: Post:

User: Password: QTH Nickname:

eQSL MSG: Enable

Also here we leave the Server set to 127.0.0.1:

MSHV

Macros Network Configuration Radio And Frequencies Configuration

PSK Reporter Settings:

Enable PSK Reporter Spotting Use TCP/UDP Protocol

Status: **PSK Reporter Is Disabled And Disconnected**

Server: Port:

DX-Spot Settings:

Status: **Disconnected**

Server: Port:

Telnet Clusters:

UDP Broadcast Settings:

Enable Logged QSO Enable Logged QSO ADIF Enable Decoded Text

Status: **Connected to Enzo IP 127.0.0.1**

Server: Port:

Write Status Info In To File (settings/mshv_status.txt)

Simplified UDP Broadcast: Enable Logged QSO ADIF

Server: Port:

TCP Broadcast Settings: - DXKeeper Formatted Message -

Server: Port: Enable Logged QSO

Club Log Real-Time Upload Logged QSO:

Server: Port: Post:

E-Mail: Password: Callsign: **IK8OZV** Enable

QRZ Logbook Real-Time Upload Logged QSO:

Server: Port: Post:

API Key: Enable


eQSL Real-Time Upload Logged QSO:

Server: Port: Post:

User: Password: QTH Nickname:

eQSL MSG: Enable

While the Door must be set to 2333:



At this time the setting is over. There is no save or confirmation button here as with WSJT-X so you can close the window by clicking on the X at the top right.

Don't try to enable anything else otherwise EasyLog goes into scandescence and starts opening and closing the QSO input window.

Man warned half saved.

I hope I have given help to those who were looking for how to set everything to transfer the data of a qso from WSJT-X or MSHV to EasyLog.

73's and QSO vouchers in FT8 or FT4 by Enzo IK8OZV Beta-Tester, EasyLog.